

Längenangaben WBH Laser-Stativ

alle Masse in cm

Art.	Nr.	kg	Transport-Länge	Höhe bis Laser-Montagegewinde				plus Laserstrahl-Austrittshöhe ab Laser-Montagegewinde																
				min	ohne Kurbel-Hub	Kurbel-hub-Länge	Auszug-Säule Länge	maximal	PLS 2	PLS 180	PLS 4	PLS 360	FL20	FL30	FL40	FL55	PLS 100	FL1000	FP5	FL240	FL260	FL500/550	FL100 J	FL110
SL13	3550	4.2	77	68	96	39		135	4.3	4.5	5.0	6.8	9.4	6.0	6.7	14.1	15.3	16.7	11.0	15.8	17.4	20.4	15.9	16.0
SL14	1229	2.3	59	57	124	28		152																
SL18	1074	2.4	74	67	148	30		178																
SL20	1068	4.8	109	95	163	39		202																
SL24	1084	2.7	87	73	214	30		244																
SL28	1701	5.7	108	97	224	36		260																
SL30	1301	8.4	114	102	151	61	91	303																
SL32	1305	8.2	135	115	182	55	53	290																
SL40	1307	15.2	179	168	292	103		395																
KS 3	1467	1.6	73	76	335			335																